

REGULATOR SINGLE WINDOW

M-Flow Range Codes (2017-01-05).123.xlsx.pdf

FLOW RANGE	RANGE CODE	FLOW SETTINGS AS THEY APPEAR THRU WINDOW											SAE
1/10 thru 1.5	A1	0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1	1.5	A4
1/10 thru 1.5 @ 20 PSI	A1	0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1	1.5	A4
1/50 thru 3	A5	0.02	0.03	0.05	0.08	0.12	0.2	0.3	0.5	0.75	1	3	
1/50 thru 3 @ 58 PSI	A5	0.02	0.03	0.05	0.08	0.12	0.2	0.3	0.5	0.75	1	3	
1/40 thru 2	B1	0.025	0.04	0.06	0.09	0.15	0.25	0.4	0.6	0.9	1.5	2	
1/32 thru 4	D2	1/32	1/16	1/8	1/4	1/2	3/4	1	1 1/2	2	3	4	D1
1/16 thru 4	D4	0.06	0.12	0.25	0.5	0.75	1	1.5	2	2.5	3	4	
1/32 thru 5	E1	0.03	0.06	0.12	0.25	0.5	1	1.5	2	3	4	5	
1/8 thru 6	F1	0.12	0.25	0.5	0.75	1	1.5	2	3	4	5	6	
1/2 thru 8	H1	0.5	1	1.5	2	2.5	3	4	5	6	7	8	H3
1/2 thru 8 @ 20 PSI	H1	0.5	1	1.5	2	2.5	3	4	5	6	7	8	
1/2 thru 10	J1	0.5	1	1.5	2	2.5	3	4	5	6	8	10	
6 thru 12	L4	-	6	-	12	-	-	-	-	-	-	-	
1/2 thru 15	M1	0.5	1	1.5	2	3	4	5	6	8	10	15	M3
1/2 thru 15 @ 58 PSI	M1	0.5	1	1.5	2	3	4	5	6	8	10	15	M3
1/2 thru 15	M5	0.5	1	2	3	4	5	6	8	10	12	15	M7
1/32 thru 15	M6	1/32	1/16	1/8	1/4	1/2	3/4	1	1 1/2	2	6	15	M4
1/4 thru 15	MB	1/4	1/2	1	1 1/2	2	3	4	6	8	12	15	M8
1/32 thru 15	MC	A	B	C	D	E	F	G	H	I	J	K	M4
8 thru 15 @ 58 PSI	MD	8	15	-	-	-	-	-	-	-	-	-	
6 thru 12	MX	FLOW	CPR	-	-	-	-	-	-	-	-	-	
1/4 thru 25	P1	0.25	0.5	1	2	3	4	6	8	10	15	25	P3
1/4 thru 25	P2	1/4	1/2	1	2	3	4	6	8	10	15	25	P3
1/4 thru 25 @ 58 PSI	P2	1/4	1/2	1	2	3	4	6	8	10	15	25	
1 thru 25	P4	1	2	3	4	6	8	10	12	15	20	25	P6
1 thru 25 @ 20 PSI	P4	1	2	3	4	6	8	10	12	15	20	25	P6
1 thru 25 @ 70 PSI	P4	1	2	3	4	6	8	10	12	15	20	25	P6
1 thru 25 @ 70 PSI /500	P4	1	2	3	4	6	8	10	12	15	20	25	P6
1 thru 25	P5	1	2	3	4	5	6	8	10	12	15	25	PB
1/2 thru 25	P7	1/2	1	1 1/2	2	3	4	6	8	10	15	25	P8
8 thru 25	PA	8	12	15	25	-	-	-	-	-	-	-	
	PE	1/4	1/2	1	2	4	6	8	10	15	20	25	
1/2 thru 30	PD	1/2	2	4	6	8	10	12	15	20	25	30	PC
3 thru 25	PL	3	4	5	6	7	8	10	12	15	20	25	
3 thru 25 @ 70 PSI	PL	3	4	5	6	7	8	10	12	15	20	25	
1/4 thru 30	Q1	0.25	0.5	1	2	4	6	8	10	12	20	30	
4 thru 40	Q7	4	6	8	10	12	15	20	25	30	35	40	
1 thru 60	T1	1	2	3	4	5	6	10	15	25	40	60	

REGULATOR DOUBLE WINDOW

M-Flow Range Codes (2017-01-05).123.xlsx.pdf

FLOW RANGE	RANGE CODE	FLOW SETTINGS AS THEY APPEAR THRU WINDOW											SAE
25 ML thru 1 L	A2	25	50	75	100	125	150	175	200	250	500	1	
		ML	ML	ML	ML	ML	ML	ML	ML	ML	ML	L	
25 CC thru 3 L	A6	25	50	100	150	200	250	500	1	1.5	2	3	
		CC	CC	CC	CC	CC	CC	CC	L	L	L	L	
20 ML thru 3 L	C4	20	25	50	100	250	500	750	1	1.5	2	3	
		ML	ML	ML	ML	ML	ML	ML	L	L	L	L	
30 ML thru 4 L	D8	30	60	125	250	500	750	1	1.5	2	3	4	D7
		ML	ML	ML	ML	ML	ML	L	L	L	L	L	

MINI RIGHT HAND REGULATOR

FLOW RANGE	RANGE CODE	FLOW SETTINGS AS THEY APPEAR THRU WINDOW											SAE
1/2 thru 6	F5	6.0	5.0	4.0	3.5	3.0	2.5	2.0	1.5	1.0	0.75	0.50	

MINI LEFT HAND REGULATOR

FLOW RANGE	RANGE CODE	FLOW SETTINGS AS THEY APPEAR THRU WINDOW											SAE
1/2 thru 6	F2	0.50	0.75	1.0	1.5	2.0	2.5	3.0	3.5	4.0	5.0	6.0	
1/2 thru 6 @ 20 PSI	F2	0.50	0.75	1.0	1.5	2.0	2.5	3.0	3.5	4.0	5.0	6.0	
1/2 thru 8	H4	0.5	1	1.5	2	2.5	3	4	5	6	7	8	H1
1/2 thru 15	M2	0.5	1	1.5	2	3	4	5	6	8	10	15	
1/2 thru 25	P9	1/4	1/2	1	2	3	4	6	8	10	15	25	

FLOWMETER SINGLE WINDOW

M-Flow Range Codes (2017-01-05).123.xlsx.pdf

FLOW RANGE	RANGE CODE	FLOW SETTINGS AS THEY APPEAR THRU WINDOW											SAE
1/10 thru 1.5	A3	1.5	1	.90	.80	.70	.60	.50	.40	.30	.20	.10	
1/10 thru 1.5	A4	1.5	1.0	0.9	0.8	0.7	0.6	0.5	0.4	0.3	0.2	0.1	A1
1/32 thru 4	D1	4	3	2	1 1/2	1	3/4	1/2	1/4	1/8	1/16	1/32	D2
1/32 thru 4	D3	4	3	2	1.5	1.0	0.75	0.50	0.25	0.12	0.06	0.03	
1/32 thru 4 @ 58 PSI	D3	4	3	2	1.5	1.0	0.75	0.50	0.25	0.12	0.06	0.03	
1/2 thru 6	F3	6.0	5.0	4.0	3.5	3.0	2.5	2.0	1.5	1.0	0.75	0.50	
1/2 thru 6	F4	6	5	4.5	4	3.5	3	2.5	2	1.5	1	0.5	
1/2 thru 8	H2	8	7.5	7	6.5	6	5.5	5	4	3	2	1	
1/2 thru 8	H3	8	7	6	5	4	3	2.5	2	1.5	1	.5	H1
0 thru 8	H4	8	-	-	-	-	-	-	-	-	-	-	
1/2 thru 15	M3	15	10	8	6	5	4	3	2	1.5	1	.5	M1
1/2 thru 15 @ 58 PSI	M3	15	10	8	6	5	4	3	2	1.5	1	.5	M1
1/32 thru 15	M4	15	6	2	1 1/2	1	3/4	1/2	1/4	1/8	1/16	1/32	M6
1/2 thru 15	M7	15	12	10	8	6	5	4	3	2	1	1/2	M5
1/4 thru 15	M8	15	12	8	6	4	3	2	1 1/2	1	1/2	1/4	MB
1/16 thru 15	M9	15	10	8	5	3	2	1	0.50	0.25	0.12	0.06	
4 thru 15	MA	15	14	13	12	11	10	8	7	6	5	4	
1/8 thru 16	N1	16	8	6	2.5	2	1.5	1	3/4	1/2	1/4	1/8	
1/8 thru 16 @ 17 PSI	N1	16	8	6	2.5	2	1.5	1	3/4	1/2	1/4	1/8	
1/4 thru 25	P3	25	15	10	8	6	4	3	2	1	.5	.25	P1
1 thru 25	P6	25	20	15	12	10	8	6	4	3	2	1	P4
1 thru 25 @ 30 PSI	P6	25	20	15	12	10	8	6	4	3	2	1	P4
1 thru 25 @ 70 PSI	P6	25	20	15	12	10	8	6	4	3	2	1	P4
1/2 thru 25	P8	25	15	10	8	6	4	3	2	1 1/2	1	1/2	P7
1 thru 25	PB	25	15	12	10	8	6	5	4	3	2	1	P5
1/2 thru 30	PC	30	25	20	15	12	10	8	6	4	2	0.5	PD
10 thru 40	Q5	40	38	35	32	30	28	25	22	20	15	10	
1/2 thru 40	S1	40	15	10	8	6	5	4	3	2	1	0.5	
1/4 thru 60	T2	60	25	10	8	6	4	3	2	1	0.50	0.25	
1/4 thru 60	T3	60	40	15	10	8	6	2	1	0.75	0.50	0.25	

FLOWMETER DOUBLE WINDOW

FLOW RANGE	RANGE CODE	FLOW SETTINGS AS THEY APPEAR THRU WINDOW												SAE
30 ML thru 4 L	D7	4	3	2	1.5	1	750	500	250	125	60	30	D8	
		L	L	L	L	L	ML	ML	ML	ML	ML	ML		
30 ML thru 4 L @ 58 PSI	D7	4	3	2	1.5	1	750	500	250	125	60	30	D8	
		L	L	L	L	L	ML	ML	ML	ML	ML	ML		
10 thru 18	R1	-	-	-	-	-	-	-	18L	18L	10L	10L		
		-	-	-	-	-	-	-	18L	0	10L	0		

BLENDER FLOWMETER SINGLE WINDOW

FLOW RANGE	RANGE CODE	FLOW SETTINGS AS THEY APPEAR THRU WINDOW												SAE
1 thru 5	Y1	1	2	3	4	5	-	-	-	-	-	-		

FLOW CONTROL VALVE, DIRECT FLOW

FLOW RANGE	RANGE CODE	FLOW SETTINGS AS THEY APPEAR THRU WINDOW												SAE
1/8 thru 6 @ 19.5 PSI	DA	0.12	0.25	0.5	0.75	1	1.5	2	2.5	3	3.5	4		
1/8 thru 6 @ 22 PSI	D9	0.12	0.25	0.5	0.75	1	1.5	2	2.5	3	3.5	4		
1/4 thru 6 @ 22 PSI	F7	0.25	0.5	0.75	1	1.5	2	2.5	3	4	5	6		
1/4 thru 6 @ 19.5 PSI	F8	0.25	0.5	0.75	1	1.5	2	2.5	3	4	5	6		
1/4 thru 6 @ 20 PSI	FB	0.25	0.5	0.75	1	1.5	2	2.5	3	4	5	6		
1/2 thru 15 @ 22 PSI	ME	0.5	1	1.5	2	3	4	5	6	8	10	15		
1/2 thru 10 @ 19.5 PSI	J3	0.5	0.75	1	1.5	2	3	4	5	6	8	10		

FLOW CONTROL VALVE, REVERSE FLOW

FLOW RANGE	RANGE CODE	FLOW SETTINGS AS THEY APPEAR THRU WINDOW												SAE
1/2 thru 10 @ 22 PSI	J2	0.5	0.75	1	1.5	2	3	4	5	6	8	10		
1/4 thru 6 @ 22 PSI	F9	0.25	0.5	0.75	1	1.5	2	2.5	3	4	5	6		
1/4 thru 6 @ 50 PSI	FA	0.25	0.5	0.75	1	1.5	2	2.5	3	4	5	6		